

MISC. PARTS LIST

Single Duct Variable Volume Control Assemblies - Direct Digital Controls

SDV

v001 – Issue Date: 07/23/24

© 2024 Price Industries Limited. All rights reserved.

PRICE[®]

INSTRUCTIONS


MISC. PARTS LIST

Using the Parts List Line String

1. Locate desired component and line string on MISC. Parts list.
2. Copy desired line string on the document.

COMPONENT	DESCRIPTION	LINE STRING	PART #
	SP300 Cross Flow Sensor Size 4 to 6	MISC-PARTS//TerminalUnits/Cross Flow Sensor/SP300/size 4 to 6///SP300 AIR FLOW SENSOR size6 REV A/041688-001	041688-001

3. Paste the line string into the search bar in the All-In-One software.



4. Click enter to populate the MISC-Parts selection into your AIO Schedule.

The screenshot shows the software's main interface with the 'Home Schedule (All Products) [Default]' table. The table has columns for Status, #, Qty, Model, Tag, List Price, and Linestring. The first row shows a green circle icon, a quantity of 1, and the line string 'MISC-PARTS//TerminalUnits/Cross Flow Sensor/SP300/size 4 to 6///SP300 AIR FLOW SENSOR size6 REV A/041688-001'. The 'List Price' column shows '\$8.18'. Below the table, there is a 'Project Summary' section with fields for 'Job Name' and 'Location', and a 'Total Net' value of \$8.18.

Finding a Component Given a Part Number

1. Search given part number on the lists parts (Ctrl + F).

COMPONENT	DESCRIPTION	LINE STRING	PART #
	SP300 Cross Flow Sensor Size 4 to 6	MISC-PARTS//TerminalUnits/Cross Flow Sensor/SP300/size 4 to 6///SP300 AIR FLOW SENSOR size6 REV A/041688-001	041688-001

2. Find corresponding line string next to the part number and copy the line string into All-In-One and follow the instructions above to add the component to your schedule.

COMPONENT	DESCRIPTION	LINE STRING	PART #
	SP300 Cross Flow Sensor Size 4 to 6	MISC-PARTS//TerminalUnits/Cross Flow Sensor/SP300/size 4 to 6///SP300 AIR FLOW SENSOR size6 REV A/041688-001	041688-001

SINGLE DUCT VARIABLE VOLUME CONTROL ASSEMBLIES

MISC. PARTS LIST

COMPONENT	DESCRIPTION	LINE STRING	PART #
Sensors	SP300 Cross Flow Sensor Size 4 to 6	MISC-PARTS//I/TerminalUnits/Cross Flow Sensor/SP300/size 4 to 6///SP300 AIR FLOW SENSOR size6 REV A/041688-001	041688-001
	SP300 Cross Flow Sensor Size 7	MISC-PARTS//I/TerminalUnits/Cross Flow Sensor/SP300/size 7///SP300 AIR FLOW SENSOR size 7 REV A/041688-002	041688-002
	SP300 Cross Flow Sensor Size 8, Size 24x16 (qty. 4 required)	MISC-PARTS//I/TerminalUnits/Cross Flow Sensor/SP300/size 8///SP300 AIR FLOW SENSOR size 8 REV A/041688-003	041688-003
	SP300 Cross Flow Sensor Size 9	MISC-PARTS//I/TerminalUnits/Cross Flow Sensor/SP300/size 9///SP300 AIR FLOW SENSOR size 9 REV A/041688-004	041688-004
	SP300 Cross Flow Sensor Size 10	MISC-PARTS//I/TerminalUnits/Cross Flow Sensor/SP300/size 10///SP300 AIR FLOW SENSOR size 10 REV A/041688-005	041688-005
	SP300 Cross Flow Sensor Size 12	MISC-PARTS//I/TerminalUnits/Cross Flow Sensor/SP300/size 12///SP300 AIR FLOW SENSOR size 12 REV A/041688-006	041688-006
	SP300 Cross Flow Sensor Size 14	MISC-PARTS//I/TerminalUnits/Cross Flow Sensor/SP300/size 14///SP300 AIR FLOW SENSOR size 14 REV A/041688-007	041688-007
	SP300 Cross Flow Sensor Size 16	MISC-PARTS//I/TerminalUnits/Cross Flow Sensor/SP300/size 16///SP300 AIR FLOW SENSOR size 16 REV A/041688-008	041688-008
	Cross Flow Sensor Tubing-Green, Low Signal	MISC-PARTS//I/TerminalUnits/Cross Flow Sensor Tubing/Green(1ft) CDN/// TUBING DEKRON .25 inch GREEN/041460-003	041460-003
	Cross Flow Sensor Tubing-Red, High Signal	MISC-PARTS//I/TerminalUnits/Cross Flow Sensor Tubing/Red(1ft) CDN/// TUBING DEKRON .25 inch RED/041460-002	041460-002
	Miscellaneous	Protective Shroud	MISC-PARTS//I/TerminalUnits/Protective Shroud/Cover only/////219629-001
Hanger Brackets (L shaped)		MISC-PARTS//I/TerminalUnits/Hanger Brackets/All terminals (L shaped)(1 piece)/////Formed Hanger Bracket for FPTU/222628-001	222628-001
Canada Plug DP-625		MISC-PARTS//I/TerminalUnits/SDV/CANADA PLUG DP-625/////PLUG Heyco 5/8 inch DP-625/041679-002	041679-002
Inlet Adapter CDN 4 Inch		MISC-PARTS//I/TerminalUnits/SDV/Inlet Adapter CDN/4 Inch///SPV RPV INLET ADAPTOR SIZE 4/205214-001	205214-001
Inlet Adapter CDN 5 Inch		MISC-PARTS//I/TerminalUnits/SDV/Inlet Adapter CDN/5 Inch///SPV RPV INLET ADAPTOR SIZE 5/205214-002	205214-002
Genesis Snap Latch		MISC-PARTS//I/TerminalUnits/Latches/Genesis Snap Latch///LUDWIG SNAP FASTENER #A-17/027370-001	027370-001
Quarter Turn Latch		MISC-PARTS//I/TerminalUnits/Latches/Nylon Button///Button Cam Latch Valox 420SEO/041220-001	041220-001
Gauge Tap Brass Tee		MISC-PARTS//I/TerminalUnits/GAUGE TAP BRASS TEE/////041683-001	041683-001
Gauge Tap Red Cap		MISC-PARTS//I/TerminalUnits/GAUGE TAP RED CAP CDN/////041690-001	041690-001
EC Parts			
Switches	Airflow Switch	MISC-PARTS//I/TerminalUnits/ContactorsSwitchesRelays/AirFlow Switch/// Airflow Switch/019425-002	019425-002
	Airflow Switch Probe 2.5in	MISC-PARTS//I/TerminalUnits/Electric coils/AirFlow Switch Probe 2.5in/// TRIDELTA AIR PROBE -ASSY-BENT/076860-001	076860-001
	Auto Reset Limit Switch .625in	MISC-PARTS//I/TerminalUnits/Electric coils/Auto Reset Limit Switch/.625 inch Diameter Reset///Small Auto Reset Thermal Limit Switch 45C/019768-003	019768-003
	Auto Reset Limit Switch .938in	MISC-PARTS//I/TerminalUnits/Electric coils/Auto Reset Limit Switch/.938 inch Diameter Reset///Large Auto Reset Thermal Limit Switch 130F/019768-001	019768-001
Door Disconnect Switch	Door Disconnect Switch 25 amp	MISC-PARTS//I/TerminalUnits/Electric coils/Door Disconnect Switch/25 amp/ Eaton//Door Disconnect Switch 600V 25A/019774-006	019774-006
	Door Disconnect Switch 40 amp	MISC-PARTS//I/TerminalUnits/Electric coils/Door Disconnect Switch/40 amp/ Eaton//Door Disconnect Switch 600V 40A/019774-007	019774-007
	Door Disconnect Switch 60 amp	MISC-PARTS//I/TerminalUnits/Electric coils/Door Disconnect Switch/60 amp/ Eaton//Door Disconnect Switch 600V 60A/019774-008	019774-008
	Door Disconnect Switch Assembly Kit 25 amp	MISC-PARTS//I/TerminalUnits/Electric coils/Door Disconnect Switch Assy Kit/25 amp/Eaton//IDSW Assembly Kit 25a 600v Eaton/217730-004	217730-004

SINGLE DUCT VARIABLE VOLUME CONTROL ASSEMBLIES

MISC. PARTS LIST

COMPONENT	DESCRIPTION	LINE STRING	PART #
Door Disconnect Switch	Door Disconnect Switch Assembly Kit 40 amp	MISC-PARTS//I/TerminalUnits/Electric coils/Door Disconnect Switch Assy Kit/40 amp/Eaton//IDSW Assembly Kit 40a 600v Eaton/217730-005	217730-005
	Door Disconnect Switch Assembly Kit 60 amp	MISC-PARTS//I/TerminalUnits/Electric coils/Door Disconnect Switch Assy Kit/60 amp/Eaton//IDSW Assembly Kit 60a 600v Eaton/217730-006	217730-006
	Door Disconnect Switch Knob	MISC-PARTS//I/TerminalUnits/Electric coils/Door Disconnect Switch Knob/Eaton//Door Disconnect Knob Assy Eaton/019780-002	019780-002
	Door Disconnect Switch shaft long	MISC-PARTS//I/TerminalUnits/Electric coils/Door Disconnect Switch shaft long/Eaton//Door Disconnect Shaft 150MM EATON/019779-005	019779-005
	Door Disconnect Switch shaft standard	MISC-PARTS//I/TerminalUnits/Electric coils/Door Disconnect Switch shaft standard/Eaton//Door Disconnect Shaft 90MM EATON/019779-004	019779-004
Fuses	FUSE 600V 10A CLASS CC 2in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600V 10A CLASS CC 2in.FUSE///Main Power Fuse/019750-001	019750-001
	FUSE 600V 10A CLASS K5 5in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600V 10A CLASS K5 5in.FUSE///Main Power Fuse/019766-002	019766-002
	FUSE 600V 15A CLASS K5 5in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600V 15A CLASS K5 5in.FUSE///Main Power Fuse/019766-003	019766-003
	FUSE 600V 20A CLASS K5 5in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600V 20A CLASS K5 5in.FUSE///Main Power Fuse/019766-004	019766-004
	FUSE 600V 25A CLASS CC 2in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600V 25A CLASS CC 2in.FUSE///Main Power Fuse/019750-006	019750-006
	FUSE 600V 25A CLASS K5 5in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600V 25A CLASS K5 5in.FUSE///Main Power Fuse/019766-005	019766-005
	FUSE 600V 30A CLASS CC 2in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600V 30A CLASS CC 2in.FUSE///Main Power Fuse/019750-007	019750-007
	FUSE 600V 30A CLASS K5 5in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600V 30A CLASS K5 5in.FUSE///Main Power Fuse/019766-006	019766-006
	FUSE 600V 35A CLASS K5 5in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600V 35A CLASS K5 5in.FUSE///Main Power Fuse/019766-007	019766-007
	FUSE 600V 40A CLASS K5 5in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600V 40A CLASS K5 5in.FUSE///Main Power Fuse/019766-008	019766-008
	FUSE 600V 45A CLASS K5 5in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600V 45A CLASS K5 5in.FUSE///Main Power Fuse/019766-009	019766-009
	FUSE 600V 50A CLASS K5 5in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600V 50A CLASS K5 5in.FUSE///Main Power Fuse/019766-010	019766-010
	FUSE 600V 5A CLASS CC 2in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600V 5A CLASS CC 2in.FUSE///Main Power Fuse/019750-013	019750-013
	FUSE 600V 5A CLASS K5 5in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600V 5A CLASS K5 5in.FUSE///Main Power Fuse/019766-001	019766-001
	FUSE 600V 60A CLASS K5 5in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600V 60A CLASS K5 5in.FUSE///Main Power Fuse/019766-011	019766-011
	FUSE 600VAC 15A CLASS CC 2in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600VAC 15A CLASS CC 2in.FUSE///Main Power Fuse/019750-003	019750-003
	FUSE 600VAC 20A CLASS CC 2in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE 600VAC 20A CLASS CC 2in.FUSE///Main Power Fuse/019750-005	019750-005
	FUSE BLOCK 1POLE 600V 30A CLASS CC 2in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE BLOCK 1POLE 600V 30A CLASS CC 2in.FUSE///Main Power Fuse Block/019765-003	019765-003
	FUSE BLOCK 1POLE 600V 30A CLASS K5 5in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE BLOCK 1POLE 600V 30A CLASS K5 5in.FUSE///Main Power Fuse Block/019764-001	019764-001
	FUSE BLOCK 1POLE 600V 60A CLASS K5 5in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE BLOCK 1POLE 600V 60A CLASS K5 5in.FUSE///Main Power Fuse Block/019764-002	019764-002
FUSE BLOCK 2POLE 600V 30A CLASS CC 2in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE BLOCK 2POLE 600V 30A CLASS CC 2in.FUSE///Main Power Fuse Block/019765-005	019765-005	
FUSE BLOCK 3POLE 600V 30A CLASS CC 2in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE BLOCK 3POLE 600V 30A CLASS CC 2in.FUSE///Main Power Fuse Block/019765-004	019765-004	

SINGLE DUCT VARIABLE VOLUME CONTROL ASSEMBLIES

MISC. PARTS LIST

COMPONENT	DESCRIPTION	LINE STRING	PART #
Fuses	FUSE BLOCK 3POLE 600V 30A CLASS K5 5in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE BLOCK 3POLE 600V 30A CLASS K5 5in.FUSE///Main Power Fuse Block/019765-001	019765-001
	FUSE BLOCK 3POLE 600V 60A CLASS K5 5in.FUSE	MISC-PARTS//I/TerminalUnits/Electric coils/FUSE BLOCK 3POLE 600V 60A CLASS K5 5in.FUSE///Main Power Fuse Block/019765-002	019765-002
Contactors	Magnetic Contactor 1 Pole 30 amp	MISC-PARTS//I/TerminalUnits/Electric coils/Magnetic Contactor/1Pole/30 amp//Magnetic Contactor 1Pole 30FLA 24-240-277V/019416-002	019416-002
	Magnetic Contactor 2 Pole 30 amp	MISC-PARTS//I/TerminalUnits/Electric coils/Magnetic Contactor/2Pole/30 amp//Magnetic Contactor 2Pole 30FLA 24-240-277V/019416-001	019416-001
	Magnetic Contactor 3 Pole 30 amp	MISC-PARTS//I/TerminalUnits/Electric coils/Magnetic Contactor/3Pole/30 amp//Magnetic Contactor 3Pole 30FLA 24-240-277V/019418-001	019418-001
	Manual Reset Limit Switch	MISC-PARTS//I/TerminalUnits/Electric coils/Manual Reset Limit Switch////Manual Reset Thermal Switch 150deg/019769-001	019769-001
	Mercury Contactor 2 Pole 30 amp	MISC-PARTS//I/TerminalUnits/Electric coils/Mercury Contactor/2Pole/30 amp//Mercury Contactor 2Pole 30AMP/019863-002	019863-002
	Mercury Contactor 2 Pole 60 amp	MISC-PARTS//I/TerminalUnits/Electric coils/Mercury Contactor/2Pole/60 amp//Mercury Contactor 2Pole 60AMP/019863-003	019863-003
Controllers	SCR Controller 25A 3 Phase	MISC-PARTS//I/TerminalUnits/Electric coils/SCR Controller/25A 3PH///SCR/019455-108	019455-108
	SCR Controller 45A 1 Phase	MISC-PARTS//I/TerminalUnits/Electric coils/SCR Controller/45A 1PH///SCR/019455-109	019455-109
	SCR Controller 45A 3 Phase	MISC-PARTS//I/TerminalUnits/Electric coils/SCR Controller/45A 3PH///SCR/019455-110	019455-110
	SCR Controller DAT Sensor	MISC-PARTS//I/TerminalUnits/Electric coils/SCR Controller DAT Sensor////Duct Probe/250000-051	250000-051
	SCR Lite Controller 10A 1 Phase	MISC-PARTS//I/TerminalUnits/Electric coils/SCR Lite Controller/1 phase 10 amp///SCR-DAT 1 PHASE 10AMP 480V/019455-111	019455-111
	SCR Lite Controller 10A 3 Phase	MISC-PARTS//I/TerminalUnits/Electric coils/SCR Lite Controller/3 phase 10 amp///SCR-DAT 3 PHASE 10AMP 480V/019455-112	019455-112
Terminal Blocks	Terminal Block Hi Voltage Foot Kad for KT3	MISC-PARTS//I/TerminalUnits/Electric coils/Terminal Block Hi Voltage/Foot Kad for KT3///TERMINAL BLOCK 3POLE Foot/21-12269	21-12269
	Terminal Block Hi Voltage Req KT3	MISC-PARTS//I/TerminalUnits/Electric coils/Terminal Block Hi Voltage/Req KT3///TERMINAL BLOCK 3POLE req Kt-FT/019949-001	019949-001
	Terminal Block Low Voltage	MISC-PARTS//I/TerminalUnits/Electric coils/Terminal Block Low Voltage////TERMINAL BLOCK 12POLE 160DKLNH/019064-013	019064-013
Transformer	Transformer 120V-24V	MISC-PARTS//I/TerminalUnits/Electric coils/Transformer/120V-24V///50VA Class2 115V-24V FT-MT/019436-001	019436-001
	Transformer 208 140-24V	MISC-PARTS//I/TerminalUnits/Electric coils/Transformer/208 240-24V///50VA Class2 208 240-24V FT-MT/019436-011	019436-011
	Transformer 277V-24V	MISC-PARTS//I/TerminalUnits/Electric coils/Transformer/277V-24V///50VA Class2 277V-24V FT-MT/019439-001	019439-001
	Transformer 480V-24V	MISC-PARTS//I/TerminalUnits/Electric coils/Transformer/480V-24V///50VA Class2 480V-24V FT-MT/00-14050	00-14050

This document contains the most current product information as of this printing.
For the most up-to-date product information, please go to priceindustries.com

© 2024 Price Industries Limited. All rights reserved.

